



Mackaderm® LIA

100% naturally-derived silicone alternative

Mackaderm® LIA

INCI: Isoamyl Laurate



- 100% naturally-derived, COSMOS certified-silicone alternative. China compliant.
- Alternative to silicones used in shampoos & rinse-off conditioners.
- Not an alternative to D4/D5
- Equivalent hair softness, lightweightness & fluidity to silicone with less build-up.
- Suitable for both Caucasian & Asian hair.
- More universal than natural oils (damage level, cleanliness/performance balance).
- Suitable for shampoos, conditioners & treatments.
- Enables the formulation of clear shampoos without adding a solubilizer.

Mackaderm® Esters in Conditioner

Formula composition used for the study

Ingredients	%wt
Deionized Water	qs 100
Cetearyl Alcohol	5.0
Glycerin	0.6
Mackaderm® Esters	4.0
Fentacare® BTMAC 180 (Behentrimonium Chloride)	3.1
Mackine® 301U (Stearamidopropyl Dimethylamine)	1.5
Glyceryl Stearate	0.5
Sodium Benzoate	0.4
Salicylic Acid	0.2
Citric Acid (50% sol)	qs pH 4.0 - 4.5

Vs


Same formulation
with
1.5%

Amodimethicone

Dow Corning 2-8566 Amino Fluid

Mackaderm® esters @ 4% in conditioner outperform amodimethicone @ 1.5%

In-Vivo Tests
3 models with highlighted hair



— Amodimethicone @ 1.5%

— Mackaderm® AR-33 @ 4%





— Mackaderm® LIA @ 4%

Dow Corning 2-8566 Amino Fluid

Versatility for Different Hair Types

vs. silicone-based conditioners from around the world

Composition of Mackaderm® LIA conditioner for each region adapted to get similar surfactant system as in the benchmark. All formulas incorporate 4% of Mackaderm® LIA



- ✓ LA: Trend of better performance on some attributes on dry state
- ✓ EMEA and AP: Global performance close to the bench
- ✓ NA: The most challenging bench. Close performance to the bench.

Focus on AP results


Benchmark



Cationic active level: 1.36%
BTAC+SAPDMA

Silicone active level: 3.80%
Dimethicone + Amodimethicone

Half Head Salon Testing – 3 models with damaged hair



Similar performance to bench on both wet and dry states with very high performance on shine, softness, detangling ability and homogeneity

Positive trend on decreasing fly-away effect

Get equivalent performance to silicone with reduced build-up !

Procedure

- Virgin hair
 - 3 panellists
 - 5 cycles of shampoo+conditioner;
- Shampoo = SLES 10% + CAPB 2%
- Conditioner formulation:
- CTAC 1.5% (active content)
 - Jaguar Optima 0.3%
 - Amodimethicone 1.5%
- or Mackaderm LIA 4.0%

L: Mackaderm® LIA

S: Amodimethicone



1st cycle



5th cycle

Less build-up than silicone with Mackaderm LIA

Silicone-Free Mackaderm® LIA Conditioner CO0051

Ingredients	%wt
Deionized Water	Qs 100
Fentacare 2231 MS I90 Behentrimonium Methosulfate (80%)	1.83
Fentacare 2231 EF Behentrimonium Chloride (80%)	3.13
Cetearyl Alcohol (50/50)	4.0
Mackester GSV Glycol stearate	0.5
Preservative	qs
MACKADERM® LIA Isoamyl Laurate	2.5


Viscosity (5 rpm) mPa.s	20,000 - 30,000
pH	4.0 - 4.5

Target damage level:
3 - 4

- Delivers equivalent performance to the exact same formula based on amodimethicone @ 1.0%

Equivalent sensory profile to the one achieved with amodimethicone

In-vivo half-head testing - Model with damage level 2-3-4



Silicone-Free Multi-Benefits Premium Hair Mask

COBR0016

Ingredients	%wt
Deionized Water	qs 100
Cetearyl Alcohol	5.0
Glycerin	4.0
Mackaderm® LIA (Isoamyl Laurate)	2.0
Jaguar® HP 105	1.0
Fentacare® BTMAC 180 (Behentrimonium Chloride)	2.9
Fentacare® 2231 MS I 90 (Behentrimonium Methosulfate)	1.25
Glycol Distearate	1.0
Shea Butter	1.0
Tocopherol Acetate	0.1
Sodium Benzoate	0.4
Salicylic Acid	0.2
Citric Acid (50% sol)	qs pH 4.0 - 4.5

**Target
damage level:
4**

Viscosity (3 rpm) mPa.s	100,000-130,000
pH	4.0 - 4.5

Extra Strength Mackaderm® LIA Hair Mask 18DLO041

Ingredients	Active content %
Deionized Water	Qs 100
Fentacare 2231 EF Behentrimonium Chloride	2.5
Stearyl Alcohol (C18)	3.5
Cetearyl Alcohol (C16-C18)	2.5
Mackester GSV Glycol stearate	0.5
Preservative	qs
MACKADERM® LIA Isoamyl Laurate	3.0
Glycerin	1.0


Viscosity (5 rpm) mPa.s	50 000
pH	4.2

Target damage level:
3 - 4

- Delivers equivalent performance to a silicone-containing market product targeting same hair type

Superior performance to a silicone-containing market product addressing same hair type

Half Head Testing – Fake Head Bleached Caucasian Hair 4 hours



Main components market benchmark: Cetyl Alcohol, Cetearyl Alcohol, Glycerin, Behentrimonium Chloride, Argan Kernel Oil, Silk Amino Acids, Dimethicone, Cyclopentasiloxane, Dimethiconol, Glycol Distearate, Glycol Stearate...

Silicone-Free Deep Conditioning Hair Mask

CO0052

Ingredients	% as supplied
Deionized Water	qs 100
Glycerin	0.5
Stearyl Alcohol (C18)	4.0
Cetearyl Alcohol (C16-C18)	2.0
Fentacare® 2232 EF (Behentrimonium Chloride)	3.1
Fentacare® 2231 MS I 90 (Behentrimonium Methosulfate)	1.8
Mackaderm® LIA (Isoamyl Laurate)	3.0
Mackaderm® Cocoa (Myristyl Oleate/Myristyl Palimate/Myristyl Stearate)	1.5
Murumuru Butter	2.0
Tocopherol Acetate	0.1
Mackester GMS	0.5
Glyceryl Stearate	0.5
Phenoxyethanol	0.4
Citric Acid (50% sol)	qs pH 4.0 - 4.5


**Target damage
level:
4 - 5**

- Delivers equivalent performance to a silicone-containing market product targeting same hair type

Viscosity (5 rpm) mPa.s	64 000
pH	4.0 - 4.5

Equivalent performance to a silicone-containing market product addressing same hair type


Half Head Testing – Fake Head Bleached Caucasian Hair 4 hours



Main components market benchmark: cetearyl alcohol, behentrimonium chloride, murumuru seed butter, cetrimonium chloride, stearamidopropyl dimethylamine, dimethicone, dimethiconol

Mackaderm® LIA enables clear shampoo formulations

- **Clear formulations (T>95%) up to 2%w of Mackaderm LIA without solubilizer**



- LIA decreases the shampoo viscosity → compensate with Cocamide MIPA, PEG-150 distearate, salt...

Component	Weight % (in active)
SLES	11.5
CAPB	2.0
Mackaderm LIA Isoamyl Laurate	1 - 2.5
Mackamide CPA Cocamide MIPA	1.5
Alkamuls S6000 PEG-150 Distearate	0.2 - 1.5 ^[1]
Jaguar® Excel	0.2
Sodium Benzoate	0.4
Salicylic Acid	0.2
Sodium Chloride	0 - 2 ^[1]
pH	5

[1] Dosage adjusted to reach 10000 mPa.s (Brookfield, 10rpm, S4)

Clarity also achieved in sulfate-free chassiss

Clear Sulfate-Free Shampoo based on Mackaderm® LIA

Ingredients	As supplied
Deionized Water	qs 100
Jaguar Excel	1.0
Mackanate EL Disodium Laureth Sulfosuccinate	15.7
Miracare SOFT S-525	20.0
Mackaderm® LIA Isoamyl Laurate	2.0
Alkamuls S6000 PEG-150 Distearate	1.55
Sodium Benzoate	0.4
Salicylic Acid	0.2
Citric Acid (50% sol)	qs pH 5.3

18JES067B

Clear

Sulfate-Free

Silicone-Free

Damaged Hair

Performance Comparison to Silicone

- Silicone benchmark: **Amodimethicone** (Dow Corning 2-8566 Amino Fluid)
- Comparison using instrumental & in-vivo half head testings
- Outcome: performance equivalent to Amodimethicone at a 1-to-1 replacement (see next slide)

Component	Weight % (in active)
SLES	11.5
CAPB	2.0
Mackaderm LIA Isoamyl Laurate	1 - 2.5
Mackamide CPA Cocamide MIPA	1.5
Alkamuls S6000 PEG-150 Distearate	0.2 - 1.5 ^[1]
Jaguar® Excel	0.2
Sodium Benzoate	0.4
Salicylic Acid	0.2
Sodium Chloride	0 - 2 ^[1]
pH	5

[1] Dosage adjusted to reach 10000 mPa.s (Brookfield, 10rpm, S4)

Performance Comparison to Amodimethicone

Wet Combing Work Reduction



Effective **wet combing** work reduction in presence of 1% LIA, similar to 1% silicone

In-Vivo Half Head Testing


	Active level	Mackaderm LIA	Amo-dimethicone
Caucasian damaged	2%		
Caucasian slightly damaged	2%		
Caucasian damaged	1%		
Caucasian virgin	1%		
Asian virgin	1%		

Similar sensory profiles for LIA and amodimethicone *

* Outside benefits on hair, improved smooth skin feel on hands with LIA

Equivalent performance to amodimethicone at a 1-to-1 replacement

In-Vivo Half Head Testing – Natural Caucasian (Indian) Hair [Damage Level 2-3]



Mackaderm® LIA Benefits

- 100% naturally-derived, COSMOS certified-silicone alternative.
 - Equivalent hair softness, lightweightness & fluidity to amodimethicone with less build-up:
 - 1-to-1 replacement in shampoo
 - 1-to-2.0 ; 1-to-2.5 replacement in conditioners
- Typical replacement ratios**
(amodimethicone-to-LIA)
- Suitable for both Caucasian & Asian hair.
 - More universal than natural oils (damage level, cleanliness/performance balance).
 - Suitable for shampoos, conditioners & treatments.
 - Enables the formulation of clear shampoos without adding a solubilizer.